

# The "3030-A" MDC Operation Guide

## Keys used with MDC controller:

Debitkey (coded to your business)  
Increase Price  
Decrease Price  
Set-up

## Price setting

- Select the cycle that you want to change the price of and insert either Increase Price key or Decrease Price key. *(Prices will change in either \$.25 increments or \$ .10 increments depending on the system you ordered)*
- Repeat the above steps to set the other cycle prices

## Initial Machine Setup

- The MDC controlled machine has many features to allow the store owner or store managers to set different parameters within the machine. The Debitkey "3030-A" controller will grant access to these features with the use of the set-up key. Please see your machine manual for instructions for setting these parameters.

## Using the setup key

- Insert the set-up key the machine will then enter set-up mode *(You may perform this function without opening the access panel on the machine)*
- To exit set-up mode push the start button repeatedly until machine has returned to the operational screen displaying your programmed prices. *(Machine is now out of set-up mode)*