

# DEBITKEY "MDC" INSTALLATION INSTRUCTIONS

*The Debitkey "MDC" controller can be installed in both washers and dryers.*

## Washer Installation

1. Turn Machine Power Off
2. Install Debitkey "MDC" mounting plate from the inside of the machine.  
*(Make sure the keyport is revealed through the opening on the face of machine).*
3. Locate "**H5**" on the (Huebsch or Speedqueen) control board. Install the **7-pin** row connector that Debitkey has provided. Make sure the orientation is such that the black wire attaches to pin one and the orange wire attaches to pin seven.
4. Locate transformer in the (Huebsch or Speedqueen) machine. There will be four red wires coming from it, and then a four pin connector with two pins missing. Insert our two yellow wires into open slots. (The open slots will be labeled on the side of the connector 1 and 4. Does not matter which yellow wire is used in either open slot.
5. Locate "**H2**" on the (Huebsch or Speedqueen) control board. Install the provided **6-pin** white connector.
6. Slide Debitkey "MDC" controller board into mounting plate. Insert copper clip into board *(This will keep the board from moving upon key insertion).*
7. To complete your installation, you will need to install the faceplate. Remove paper from adhesive backing and carefully place over machine face, allowing access to keyport.
8. Turn power on. Your installation is complete

# DEBITKEY "MDC" INSTALLATION INSTRUCTIONS

*The Debitkey "MDC" controller can be installed in both washers and dryers.*

## Dryer Installation

1. Turn Machine Power Off
2. Install Debitkey "MDC" mounting plate from the inside of the machine.  
*(Make sure the keyport is revealed through the opening on the face of machine, also a lock-washer has been enclosed to even-out the mounting plate).*
3. Locate "**H3**" on the (Huebsch or Speedqueen) control board. Install the **7-pin** row connector that Debitkey has provided. Make sure the orientation is such that the black wire attaches to pin one and the orange wire attaches to pin seven.
4. Locate "**H1**" on the (Huebsch or Speedqueen) control board. Plug the provided **2-pin** connector into the hanging connector off board within machine.
5. Locate "**H6**" on the (Huebsch or Speedqueen) control board. Install the provided **6-pin** white connector.
6. Slide Debitkey "MDC" controller board into mounting plate. Insert copper clip into board *(This will keep the board from moving upon key insertion).*
7. To complete your installation, you will need to install the faceplate. Remove paper from adhesive backing and carefully place over machine face, allowing access to keyport.
8. Turn power on. Your installation is complete

