

## Universal Test Station II ACCESSORIES

### Customer Interfaces

<u>Part Number</u>	<u>Description</u>	<u>Product that the interface is used to test</u>
0928-000128	I/F,ASM,TS,12V,8JST,INH-HI	Defender
0928-000134	I/F,ASM,TS,12V,7MLX,INH-HI,SOC	MC62 Inhibit High
0928-000137	I/F,ASM,TS,12V,6JST,INH-LO,S—	CC40/MC40/IC40
0928-000138	I/F,ASM,TS,12V,6JST,INH-NO,SSR	CC16/MC16/IC16
0928-000139	I/F,ASM,TS,12V,6JST,INH-HI,SSR	CC16/MC16/IC16
0928-000140	I/F,ASM,TS,12V,6JST,INH-HI,SOC	IC32/IC36 ONLY
0928-000141	I/F,ASM,TS,24V,6JST,INH-NO,SSR	CC16/MC16/IC16
0928-000142	I/F,ASM,TS,12V,6JST,INH-HI,S—	CC40/MC40/IC40
0928-000143	I/F,ASM,TS,24V,6JST,INH-HI,S—	CC40/MC40/IC40
0928-000144	I/F,ASM,TS,12V,3JST,INH-NO,SSR	CC33/CC37 12Volt
0928-000145	I/F,ASM,TS,24V,6JST,INH-LO,S—	CC40/MC40/IC40
0928-000153	I/F,ASM,TS,12V,6MLX,INH-HI,SOC	CC16/CC32/CC36/IC16/IC32/IC36
0928-000154	I/F,ASM,TS,12V,7MLX,INH-LO,SOC	CC62/MC62/IC62
0928-000155	I/F,ASM,TS,12V,7MLX,INH-HI,SSR	MC62 Inhibit High
0928-000156	I/F,ASM,TS,24V,3JST,INH-NO,SSR	CC33/CC37/CC33/CC37
0928-000157	I/F,ASM,TS,12V,8JST,INH-LO	Defender (CC62)
0928-000158	I/F,ASM,TS,12V,8JST,INH-LO,REV	Defender
0928-000159	I/F,ASM,TS,12V,8JST,INH-HI,REV	Defender IGT Optic Emulation (IGT)
0928-000168	I/F,ASM,TS,12V,7MLX,INH HI,SOC,REV	MC16 IGT Optic Emulation (Europe Only)